

MECH TECH SYSTEMS INC. CCU MODEL FOR GLOCK PISTOLS

Operation & Maintenance Manual



Read and understand this manual before attempting to use this product. If
you have any questions call:

1-866-433-2122

www.mechtechsys.com

Made in the USA

Copyright Mech-Tech Systems, Inc.
2019 All rights reserved

MECH-TECH GLOCK* CCU OPERATION AND MAINTENANCE MANUAL

SAFETY INSTRUCTIONS AND WARNINGS

Read and understand this entire manual before attempting operation or maintenance of the CCU (Carbine Conversion Unit). Always point the muzzle in a safe direction. Assume all firearms are loaded. Take extra precautions to secure them from children. Observe all safety precautions. Wear approved ear and eye protection when firing the CCU. Obey local, state and Federal laws at all times.

Do not modify any CCU components. Doing so will void the warranty.

At all times during assembly, disassembly, and/or maintenance of the CCU make certain that the CCU and pistol frame are clear of any ammunition. The magazine must be removed from the pistol before assembly.

The CCU bolt is a spring loaded assembly. When the bolt handle is in the locked position it is possible under certain conditions for the bolt to slam shut (bolt handle bumped, jarred, etc.) Keep fingers clear of the ejection port to avoid injury.

Be certain to read and understand all assembly and disassembly instructions before using your CCU. Always wear appropriate eye protection during these procedures.

When the CCU is installed on the frame of the pistol for which it was designed, the complete assembly becomes a functioning firearm. This assembly operates in the same semi-automatic mode as the pistol from which the lower unit originated, however the bolt does **NOT** lock open after the last round has been fired. Observe all of the safety precautions which apply to the pistol as outlined by the pistol manufacturer.

Use only ammunition of the caliber for which the CCU is designed. Only use high quality ammunition loaded by licensed commercial ammunition manufacturers (factory ammunition) which meets applicable SAAMI, CIP or NATO standards. The use of reloads or ammunition from unknown suppliers has the potential to be unsafe and also will void the warranty of the CCU.

WARNING: NEVER USE AMMUNITION WITH PRESSURE LEVELS THAT EXCEED INDUSTRY STANDARDS. ALL WARRANTIES, EXPRESS AND IMPLIED WILL BE VOIDED. THE MECH-TECH CCU IS DESIGNED TO FIRE UP TO +P AMMUNITION. NEVER USE AMMUNITION WITH HIGHER PRESSURE LEVELS. MECH-TECH SYSTEMS INC. WILL NOT BE LIABLE FOR PROPERTY DAMAGE OR PERSONAL INJURY AND CONSEQUENTIAL DAMAGES. USE ONLY UNMODIFIED PISTOL LOWERS. MECH TECH REQUIRES THE SAME CRITERIA FOR SAFETY THAT IS REQUIRED BY PISTOL MANUFACTURERS. AFTERMARKET PARTS AND OTHER MODIFICATIONS TO PISTOL FRAMES MAY NOT FUNCTION WHEN USED WITH THE CCU AND MAY VOID YOUR WARRANTY.



NEVER TRY TO REMOVE YOUR FRAME FROM THE CCU WITH A ROUND CHAMBERED. DOING SO MAY CAUSE THE CCU TO FIRE RESULTING IN POSSIBLE INJURY.

1) INSTALLATION:

Fig. 1 & Fig.2 show a Glock CCU and indicate the major components and features involved. Observe in **Fig. 2** the tab relief openings which allow for the assembly of the Glock Pistol frame onto the CCU housing. **Fig. 2** also shows the metal "tabs" on the Glock pistol frame and the correct orientation of the magnetic feed ramp.

First prepare your pistol for assembly by removing the magazine. ALWAYS CHECK THAT THE CHAMBER IS CLEARED BEFORE PROCEEDING. Remove the slide assembly from the pistol. Place the feed ramp in the pistol frame with the slanted end (ramp) facing the magazine well. The magnet will hold it to the Locking Bar in the pistol. Next, pull the CCU bolt to the rear and lock it in place by pushing the bolt handle into the detente in the housing.

Hold the CCU in one hand and the pistol frame in the other, pointing in a safe direction. Match the tabs on the pistol to the tab relief openings on the CCU. With the pistol evenly pressed against the underside of the CCU push the pistol forward until the Slide Lock clicks up into place. If needed, you can place the muzzle against a firm non-marring surface to lock the pistol into place. Make certain the Slide Lock is fully engaged.



Once the pistol is properly attached to the CCU the magazine can be inserted. To chamber the first round pull the bolt handle out of the detente and release. The bolt will slam forward and chamber the cartridge. THE CCU IS NOW READY TO FIRE.

The assembled Mech Tech CCU will function just like a semi-automatic pistol, one shot per trigger pull. Safety always comes first. It is the responsibility of the operator to be aware of the condition of the CCU at all times. **Tip:** When the bolt is closed, the rear portion of the cartridge case is visible through the ejection port. This allows you to verify visually that a round is chambered and ready to fire.

2) DISASSEMBLY

Remove the magazine from the pistol frame and lock the bolt open. INSPECT THE CHAMBER AND MAKE CERTAIN IT IS CLEAR.

Place the barrel against a non-marring surface if needed. While pressing forward on the pistol frame, use your other hand to lower the Slide Lock lever. Only apply enough pressure on the pistol frame to release the tension on the Slide Lock. Slide the pistol frame rearward and off the CCU. Remove the feed ramp. Disassembly is complete. To ease disassembly an extended Slide Lock is available from after market sources.

3) MAINTENANCE

It is not necessary to "Field Strip" the CCU after each use. Under normal use the CCU

can be thoroughly cleaned using the methods outlined in this manual. With the pistol frame removed inspect the chamber to ensure the CCU is not loaded. Lock the bolt open. It is advised to hold the bolt handle firmly against the housing when cleaning. The bolt can inadvertently slam closed causing injury. Clean the barrel bore and chamber the same as with other firearm systems.

The inside of the housing in the areas where the bolt slides can be cleaned most effectively using an aerosol type gun solvent. After it is clean, wipe dry and apply lubricant as needed. Mech Tech recommends using a light oil sparingly. Over lubrication in a blow back action causes excessive build up, so only apply as needed.

4) FIELD STRIPPING

Before attempting disassembly be certain to read these instructions all the way through. Always wear suitable eye protection when working on or cleaning the CCU.

There are three major sub-assemblies in the CCU. These are:

- Barrel assembly
- Bolt Channel sub-assembly
- Main Housing sub-assembly

Disassembly instructions vary depending on the rail system your CCU has installed.

FOR DISASSEMBLY OF THE BASE MODEL:

1. Open Bolt and check that the chamber is clear. Close bolt.
2. Remove Bolt handle with a 5/32" hex wrench.
3. Remove the eight (8) screws in the Fore grip with a 9/64" hex wrench.
4. Pull the barrel and slide the complete assembly out of the housing. (NOTE: The barrel and bolt channel assemblies are held together with the recoil spring. Keep the two assemblies flat to prevent the spring from sliding off the retaining posts on either end. Use a suitable tool to retain one end and remove the spring from the post. (WARNING: ALWAYS RETAIN THE RECOIL SPRING WHEN REMOVING. FAILURE TO DO SO WILL DAMAGE THE SPRING AND REQUIRE REPLACEMENT.) Separate the barrel assembly from the bolt channel assembly. No further disassembly is required. DO NOT REMOVE THE BREACH BLOCK ASSEMBLY. THIS WILL VOID YOUR WARRANTY.

DISASSEMBLY INSTRUCTIONS FOR CCU'S WITH THE QUAD-RAIL:

Follow steps 1-2 under BASE MODEL.

Remove the bottom rail using a 3/32" hex wrench.

Remove the Side Rails and Lower Housing Clamp.

Remove the 3/32" screw at the end of the long rail. DO NOT REMOVE the Barrel Clamp.

Remove the eight(8) screws securing the Barrel assembly with a 9/64" hex wrench.

Follow step 4 under Base Model.

DISASSEMBLY INSTRUCTIONS FOR CCU'S WITH THE MONO-RAIL AND MINI-RAIL KIT:

Follow steps 1-3 under BASE MODEL.

Remove the 3/32" screw at the end of the long rail. Do not remove the barrel clamp.

Follow Step 4 under BASE MODEL.

For MINI-RAIL KITS LOOSEN ONLY the side and bottom MINI-RAILS. Follow Step 4 under BASE MODEL.

DISASSEMBLY INSTRUCTIONS FOR CCU'S WITH THE MINI QUAD-RAIL:

Follow steps 1-3 under BASE MODEL.

LOOSEN ONLY the eight (8) screws retaining the Mini-rails.

Follow step 4 under BASE MODEL.

REASSEMBLY INSTRUCTIONS-BASE MODEL:

1. Make sure Front Buffer (white disk) is installed on the barrel assembly. Slide the barrel and bolt channel assemblies together. Reinstall Recoil Spring on posts.
2. Apply a small amount of lubricant to bolt channel and inner housing and slide assembly into the

housing. **CAUTION:** RAISE THE EJECTOR ON THE CCU SO IT SLIDES UP ON TOP OF THE INSERT. FAILURE TO DO SO MAY BREAK/DAMAGE THE EJECTOR.

3. Remove the Fore grip and install four(4)screws in one side of the Housing. **NOTE:** CHECK THAT THE SCREW HEADS DO NOT PINCH THE HOUSING WHEN TIGHTENING. Lay the Fore grip over the screw heads and snap it over the Housing. Reinstall the four(4) remaining screws. Reinstall the Bolt Handle. Cycle the bolt and check that it is moving freely.

REASSEMBLY INSTRUCTIONS-CCU'S WITH THE QUAD-RAIL:

Follow steps 1-2 under BASE MODEL. Reinstall the eight(8) 9/64" hex screws in the Housing. NOTE: CHECK THAT THE SCREW HEADS DO NOT PINCH THE HOUSING WHEN TIGHTENED.

Reinstall screw in the Top Rail to Barrel Bracket.

Reinstall Side Rails and Lower Housing Clamp.

Reinstall lower rail.

Reinstall Bolt Handle.

REASSEMBLY INSTRUCTIONS FOR MONO-RAIL, MINI-RAIL KIT AND MINI-QUAD RAIL MODELS:

Follow steps 1-3 under base model.

Reinstall screw at end of long rail if needed.

Reinstall the Bolt Handle.

Tighten all of the short rails.

IF YOU HAVE ANY QUESTIONS CONCERNING ANY OF THESE PROCEDURES PLEASE CALL TECH SUPPORT AT 866-433-2122.

*DISCLAIMER NOTE: "GLOCK" is a registered trade mark and Mech Tech Systems Inc. is not affiliated with GLOCK. GLOCK has not endorsed the CCU and the fact that Mech Tech Systems Inc. provides the CCU as a GLOCK accessory is in no way intended to imply that GLOCK sanctions or is in any way associated with our product.

WARRANTY:

For one year from the date of purchase to the ORIGINAL owner, if the Mech Tech Systems CCU is operated and maintained according to the instructions in the owner's manual, Mech Tech Systems will repair or replace, free of charge, any part found to be defective in material or workmanship. CUSTOMERS ARE RESPONSIBLE FOR SHIPPING CHARGES for returning products to the factory. Mech Tech will pay return shipping (U.S. customers only) for warranty repairs. Customers are responsible for all shipping/handling charges on non-warranty repairs. Contact Mech Tech Systems for return details.

This warranty does not cover:

Items which become worn during normal use.

Repairs necessary because of abuse, negligence, accident, or failure to maintain or operate according to the owner's manual.

Unauthorized modifications to the CCU.

CCU that is used for commercial or rental purposes.

Mech Tech Systems Inc.
3247 U.S. Highway 93 South
Kalispell, MT. 59901
www.mechtechsys.com
1-866-433-2122

Copyright Mech Tech Systems Inc.
2019 All rights reserved