

## QUAD-RAIL INSTALLATION INSTRUCTIONS:

Step 1: Remove Short Rail from CCU housing.

Step 2: Remove the eight (8) 9/64" hex screws securing the fore grip. Slide the fore grip off the housing. Reinstall the screws. (NOTE: make certain the screw heads do not pinch the housing ).

Step 3: Refer to the figure below. Install the Upper Barrel Bracket to the end of the Top Rail using screw "A". Align Bracket so it is flush with the end of the Top Rail. Install the Upper Housing Bracket to the Top Rail using screw "B" (NOTE: The Upper Housing Bracket DOES NOT have threaded holes. Attach Top Rail assembly to housing using two (2) hex nuts supplied. CAUTION: DO NOT over tighten hex nuts.

Step 4: Install Lower Barrel Bracket using screws "C". Tighten so gap is even on both sides of brackets.

Step 5: Install Side Rails to Upper Barrel Bracket using screw "A". DO NOT tighten screws yet. Install Lower Housing Bracket using screws "D". Tighten screws "D", then screws "A".

Step 6: Install Lower Rail with screw "E" into Barrel Bracket and screw "B" into Housing Bracket. Installation is complete.

